

TECHNICAL BULLETIN: **2010.01**

Subject: PreFixx® Protective Finish and Chemical Resistance

Summary: OMNOVA Solutions manufactures a variety of coated fabrics used in healthcare environments, including reception and patient seating, therapy chairs, examination tables and physician stools. This upholstery needs to be durable as well as cleaned and disinfected with a variety of chemicals without worrying about discoloration or damage to the upholstery finish. OMNOVA Solutions recommends coated fabrics with **PreFixx** Protective Finish for these applications.

Chemical Resistance: **PreFixx** protected upholstery can be easily cleaned and disinfected and has been shown to have excellent chemical resistance.

The following list of cleaners and disinfectants can be safely used on OMNOVA's upholstery with **PreFixx** Protective Finish. In laboratory testing, **PreFixx** protected upholstery was scrubbed 300+ cycles with no discoloration or damage to the upholstery:

- Asepticare TB-II
- Birex® SE Disinfectant
- Bleach-Rite® Disinfecting Spray
- Cavicide® Surface Disinfectant
- Citrace® Germicide
- CitriGuard® II Hard Surface Disinfectant
- Clorox® Germicidal Wipes
- Diluted Bleach Solution
- Dispatch® Spray Hospital Cleaner Disinfectant with Bleach
- Fade-A-Dyne® Stain Remover
- Fresh Breeze TB Disinfectant
- Isopropyl Alcohol
- Lysol® Spray Disinfectant
- OPTIM™ 33TB Disinfectant
- Precise™ Hospital Cleaner
- PDI® Super Sani-Cloth® Germicidal Wipes
- PDI Sani-Cloth HB Germicidal Wipes
- PDI Sani-Cloth Plus Germicidal Wipes
- Virex® II 256 Cleaner
- Wex-Cide™ 128 Cleaner

Continued on reverse.

OMNOVA Solutions has an extensive range of coated fabrics which feature the proprietary **PreFixx** Protective Finish for a wide range of end uses and applications. The following list of coated fabrics include the industry-leading **PreFixx** Protective Finish:



Boltaflex products – serving architects, designers and OEMs for contract, healthcare and select residential applications.

- All Star
- ColorGuard
- Corsica
- Edo
- Fleur
- Grand Sierra
- Harmony
- Levante
- Rolling Stone
- Vegas
- Venue
- Vista
- Vivo



Pinnacle performance fabrics – high performance, non-PVC coated fabrics designed for Original Equipment Manufacturers, architects, designers or facility managers seeking an alternative to PVC.

- Cascade



Nautolex products – meeting the needs of the marine industry for over 50 years.

- Boat Topping
- CamoGrass
- CamoLeaf
- CamoWoods
- Grand Cayman
- Mariner
- Mariner X-tra
- Mercury
- Neptune
- New Porter
- Nexus
- Odyssey
- Punch
- SofDura
- SofDura X-tra
- Sojourn
- Torino Tradewind
- Turbo
- Voyager



BoltaSoft products – delivering performance-coated fabrics to the aftermarket industry.

- All Star
- Grand Cayman
- Harpoon
- Rogue



For the latest designs, more information, or to order, contact OMNOVA Solutions:

866.332.5226
upholstery@omnova.com
www.omnova.com/products/upholstery/upholstery.aspx

ASEPTICARE is a registered trademark of ECOLAB Inc.
 BIREX is a registered trademark of Young Dental Manufacturing
 BLEACH-RITE is a registered trademark of Current Technologies, Inc.
 CAVICIDE is a registered trademark of Metrex Research Corporation
 CITRIGUARD is a registered trademark of Riddell & Associates, Inc.
 CLOROX, DISPATCH and CITRACE are registered trademarks of The Clorox Company
 FADE-A-DYNE is a registered trademark of David P. Russ III
 FRESH BREEZE is a trademark of Misco Products Corp.
 LYSOL is a registered trademark of Reckitt Benckiser, Inc.
 OPTIM is a registered trademark of SciCan Ltd.
 PDI and SANI-CLOTH are registered trademarks of Professional Disposables Intl., Inc.
 PRECISE is a trademark of Caltech Industries, Inc.
 VIREX is a registered trademark of Diversey, Inc.
 WEX-CIDE is a trademark of Wexford Labs, Inc.



OMNOVA Solutions Inc. • 175 Ghent Road • Fairlawn, OH 44333
 Telephone: 330-869-4200 • www.omnova.com

BOLTAFLEX, BOLTASOFT, NAUTOLEX and PREFIXX are registered trademarks and PINNACLE is a trademark of OMNOVA Solutions Inc.
 ALL OMNOVA PRODUCTS AND SERVICES ARE OFFERED AND SOLD SUBJECT TO THE OMNOVA STANDARD TERMS AND CONDITIONS OF SALE AGREEMENT SET FORTH AT WWW.OMNOVA.COM

© 2010 OMNOVA Solutions Inc. 9/10